

JETYD

TOOL MODEL: ICE-1

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	196	27	266	104
1600	209	29	283	110
1800	235	33	319	124
2000	261	36	354	138
2200	288	40	390	152
2400	315	44	426	165
2600	341	47	463	179
2800	368	51	499	193
3000	395	55	535	207
3200	421	58	571	220
3400	447	62	606	234
3600	473	65	641	248
3800	499	69	676	262
4000	525	73	712	276
4200	551	76	747	290
4400	577	80	782	303
4600	603	83	817	317
4800	629	87	853	331
5000	655	91	888	345
5200	680	94	922	358
5400	705	98	956	372
5600	730	101	990	386
5800	755	104	1023	400
6000	780	108	1057	414
6200	805	111	1092	427
6400	831	115	1126	441
6600	856	118	1161	455
6800	882	122	1195	468
7000	907	125	1230	482
7200	932	129	1263	496
7400	957	132	1297	510
7600	981	136	1330	524
7800	1006	139	1364	538
8000	1031	143	1398	552
8200	1056	146	1432	565
8400	1081	150	1466	579
8600	1107	153	1500	593
8800	1132	157	1534	607
9000	1157	160	1568	620
9200	1182	164	1603	634
9400	1208	167	1637	648
9600	1233	171	1672	662
9800	1259	174	1706	676
10000	1284	178	1741	690

JETYD

TOOL MODEL: ICE-3

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	FT. LBS.	TORQUE IN		PRESSURE IN BAR
		KGM	NM	
1500	445	62	603	104
1600	475	66	644	110
1800	536	74	727	124
2000	597	83	809	138
2200	658	91	893	152
2400	720	100	976	165
2600	781	108	1059	179
2800	843	117	1142	193
3000	904	125	1225	207
3200	965	133	1308	220
3400	1026	142	1391	234
3600	1088	150	1474	248
3800	1149	159	1557	262
4000	1210	167	1640	276
4200	1270	176	1722	290
4400	1330	184	1803	303
4600	1391	192	1885	317
4800	1451	201	1967	331
5000	1511	209	2048	345
5200	1571	217	2130	358
5400	1631	226	2211	372
5600	1691	234	2292	386
5800	1751	242	2374	400
6000	1811	250	2455	414
6200	1869	259	2534	427
6400	1928	267	2613	441
6600	1986	275	2692	455
6800	2045	283	2772	468
7000	2103	291	2851	482
7200	2161	299	2929	496
7400	2219	307	3008	510
7600	2277	315	3087	524
7800	2335	323	3165	538
8000	2393	331	3244	552
8200	2451	339	3322	565
8400	2508	347	3400	579
8600	2566	355	3478	593
8800	2623	363	3556	607
9000	2681	371	3634	620
9200	2739	379	3712	634
9400	2796	387	3791	648
9600	2854	395	3869	662
9800	2911	403	3947	676
10000	2969	411	4025	690

* ISO DOCUMENT 9000

HYTORC

TOOL MODEL: ICE-5

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	804	111	1090	104
1600	858	119	1163	110
1800	965	133	1308	124
2000	1072	148	1453	138
2200	1179	163	1599	152
2400	1286	178	1744	165
2600	1394	193	1889	179
2800	1501	208	2034	193
3000	1608	222	2180	207
3200	1715	237	2325	220
3400	1822	252	2470	234
3600	1930	267	2616	248
3800	2037	282	2761	262
4000	2144	297	2906	276
4200	2251	311	3052	290
4400	2358	326	3197	303
4600	2466	341	3342	317
4800	2573	356	3488	331
5000	2680	371	3633	345
5200	2787	385	3778	358
5400	2894	400	3924	372
5600	3002	415	4069	386
5800	3109	430	4214	400
6000	3216	445	4360	414
6200	3323	460	4505	427
6400	3430	474	4650	441
6600	3538	489	4796	455
6800	3645	504	4941	468
7000	3752	519	5086	482
7200	3859	534	5232	496
7400	3966	549	5377	510
7600	4074	563	5522	524
7800	4181	578	5667	538
8000	4288	593	5813	552
8200	4395	608	5958	565
8400	4502	623	6103	579
8600	4610	638	6249	593
8800	4717	652	6394	607
9000	4824	667	6539	620
9200	4931	682	6685	634
9400	5038	697	6830	648
9600	5146	712	6975	662
9800	5253	726	7121	676
10000	5360	741	7266	690